

## RKM-572 Holder



## Instruction Manual

### Included Accessories:

- Hex Screws (24 pcs)  
10-32 x 5/8"  
Hex drive
- Nylon Washers (24 pcs)
- Nylock Nuts (8 pcs)  
10-32 thread insert size
- Tinnerman Clips (16 pcs)  
10-32 thread insert size

### Required Tools:

- Crescent wrench or 3/8 wrench
- 1/8 Hex Key (1 pc) (included)

<b>Holder Assembly</b>	
	<p><b>Step 1:</b> Lay the base flat on a hard surface.</p>
	<p><b>Step 2:</b> Place the side bar vertically on top of the base (outer placement).</p>
	<p><b>Step 3:</b> Place the washer onto the screw, and insert the screw through each of the 8 bottom holes. Secure the screws with nylock nuts.</p>
	<p><b>Step 4:</b> Repeat steps 2 and 3 for the second side bar.</p>
<b>Mounting the Units</b>	
	<p><b>Step 5:</b> Slide the Tinnerman clips onto the sidebar over the holes.</p>
	<p><b>Step 6:</b> Starting from the top of the holder, place the TLM-702 monitor on top of the Tinnerman clips.</p>
	<p><b>Step 7:</b> Place the washer onto the screw and insert the screw into Tinnerman clip to secure the monitor in its place.</p>
	<p><b>Step 8:</b> Place the ITC-100 intercom on top of the Tinnerman clips right below the monitor.</p>
	<p><b>Step 9:</b> Place the washer onto the screw and insert the screw into Tinnerman clip to secure the intercom in its place.</p>
	<p><b>Step 10:</b> Place the DN-500 recorder on top of the Tinnerman clips below the intercom. <b>NOTE:</b> You may have to wiggle the unit a bit to slide it in the holder.</p>
<p><b>Step 11:</b> Place the washer onto the screw and insert the screw into Tinnerman clip to secure the recorder in its place.</p>	